

Installation Instructions, 56677 8" Post to Beam Coupler (P2B-SB-LS) 51777 8" Post to Beam Coupler (P2B-SB-IW)








-upper fasteners sold separately;
OWT Timber Screws or OWT Timber Bolts






56677



Laredo Sunset & Ironwood




Laredo Sunset (566XX series)

2 great styles

Same functionality

choose your connection lifestyle

both styles available for most products





Ironwood (517XX series)




















kit contains 2 assemblies















56677




Installation Instructions, 56677


V2.00 - Installation Instructions, Specifications and Project Plans are effective 3/28/2016 . This information is updated periodically and should not be relied upon after 2 years from 3/28/2016 . Please visit OZCOBP.com to get current information.








mark location to mount ledge



step 1















step 3 Timber Screws

Installation Instructions, 56677

V2.00 - Installation Instructions, Specifications and Project Plans are effective 3/28/2016 . This information is updated periodically and should not be relied upon after 2 years from 3/28/2016 . Please visit OZCOBP.com to get current information.







Installation Instructions, 56677

V2.00 - Installation Instructions, Specifications and Project Plans are effective 3/28/2016 . This information is updated periodically and should not be relied upon after 2 years from 3/28/2016 . Please visit OZCOBP.com to get current information.